



Part# DCTKIT Installation Kit for Day Cab & Trailer

For trailers up to 32 feet in length

All too often after-market systems are installed without the items on hand to do an OEM level install. More time and expense can be spent hunting down the correct stainless steel screws, different size wire loom, straps, grommets, etc. This kit is designed to provide all that is needed for a faster install that is done properly. It accounts for details like the loom and wire for the reverse wire trigger. It also provides an Add-A-Line fuse connector to save time and not void OEM warranties by tying into random wires.

(1) 1.0 x .25 x .25 Black Rubber Grommet: for where monitor cable comes through dash



(20) 6" Black Cable Ties: For securing camera cable in trailer and binding any excess cable



(22) #3 10-16 Stainless Steel Pan-head Self-Drilling Screws for mounting camera, monitor, and coil cable connectors.



50' 1/4" dia. Black Wire Loom for reverse trigger wire, camera cable in cab, power and ground leads.



65' 7/16" dia. Black Wire Loom: For trailer camera cable run.

(1) Add-A Line Fuse Connector: add-aline fuse connector w/ 3 amp fuse for connecting power positive



(1) 5 Amp Fuse for Add-A-Line Fuse Connector



(1) Posi-Tap® 14-16 ga Tap (for connecting the rear trigger wire to the back-up light)



(1) Posi-Lock® 14-16 ga. Butt Splice (for connecting the piggy-back fuse connector to power supply)



10' Red 16 Gauge TEW Stranded Wire: Power wire extension

10' Black 16 Gauge TEW Stranded Wire: Ground wire extension

25' Brown 16 Gauge TEW Stranded Wire: Reverse trigger wire connection

